

DEADpedal	Rev. A	Page 1 of 1
Instructions	Tools/ Parts	Picture/ Illustration


READ FITTING INSTRUCTIONS IN FULL BEFORE INSTALLATION

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK.

By purchasing this product and opening the packaging, purchasers expressly acknowledge, understand and agree that they take, select and purchase these SECTOR 111 products from SECTOR 111, its affiliates, distributors, and agents (collectively, SECTOR 111) **as is and with all faults.**

The entire risk as to the quality and performance of these SECTOR 111 parts is with the purchasers. Working on your car can be a dangerous activity. If you are unsure of what you are doing, please leave mechanical or Safety critical work to a skilled mechanic.

We take no responsibility for the incorrect use and/or installation of SECTOR 111 products.

<ol style="list-style-type: none"> Confirm the following items are in your kit. <ul style="list-style-type: none"> DEADpedal 4 - rivets 		
<ol style="list-style-type: none"> Locate Dead Pedal. <ul style="list-style-type: none"> Hold in place on Drivers lower frame tube. <p><i>*Note : We recommend placing the DEADpedal a min of 1/4" rearward of the clutch pedal</i></p> Mark holes with black marker Using center punch and hammer mark holes where black marker was applied in previous step 	<p>Tools needed for this install:</p> <ul style="list-style-type: none"> Black Marker Center Punch Hammer 	
<ol style="list-style-type: none"> Drill Holes Using supplied 3/16" rivets, rivet dead pedal to frame rail. 	<ul style="list-style-type: none"> 3/16" Drill Bit Cordless Drill Hand Riveter 	