



READ FITTING INSTRUCTIONS IN FULL BEFORE INSTALLATION

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK.

By purchasing this product and opening the packaging, purchasers expressly acknowledge, understand and agree that they take, select and purchase these SECTOR 111 products from SECTOR 111, its affiliates, distributors, and agents (collectively, SECTOR 111) "as is" and "with all faults".

The entire risk as to the quality and performance of these SECTOR 111 parts is with the purchasers. Working on your car can be a dangerous activity. If you are unsure of what you are doing, please leave mechanical or Safety critical work to a skilled mechanic.

We take no responsibility for the incorrect use and/or installation of SECTOR 111 products.

CarbonFiber Console Installation Instructions.

Please read these instructions in full before beginning.

1. Unscrew the black 'cup holder' located back between the seats.
2. Remove the two screws holding in the gray piece that contains the power socket. Unplug the power socket. Remove this power socket from gray piece. This is the hardest part of the entire job!
3. Remove the screws on either side of the console near the front. The CF console is stiff enough to forgo the need for these screws during reassembly.
4. Pull the e-brake handle up high and hard. Remove the E-brake handle by loosening the two allen bolts located underneath.
5. Pull up the center console. Disconnect the Hazard light and Lock Switches.

* The Hazard Light Switch has a plug-ended cable leading to it. Grasp the plug and squeeze the release-tongue that is on its LHS it can be removed.

* The Lock Switch has a lead wire that is approximately 6" long. At the end of that is the plug and socket to disconnect.

6. Lift the console so that the shift boot moves up. The shift boot is retained at the shift lever by a zip-tie. Cut off the zip tie. Slide the boot off of the shifter. The

base of the boot is still clipped onto the console. The e-brake must be pulled up as high as possible to allow the stock console to come out. The shift knob does NOT need to be removed. Remove the console from car.

7. The shift boot is attached to a lip in the console cover by 6, U-shaped spring clips. Remove these clips to disconnect the shift boot.

8. Reverse steps for reassembly. You will need a zip tie to secure the shift boot to the gear lever.

*The CF rear piece that holds the power socket comes with 2 metal tabs that can be glued to it. These tabs should be positioned in the same place as the tabs on the stock part. Use the 3M primer that is included to prepare the surface of the CF where the tabs will adhere. The tabs are optional as this rear piece will be retained adequately by the 'cup holder' retaining screw.

- **Questions? info@sector111.com or 951-296-6762**