



READ FITTING INSTRUCTIONS IN FULL BEFORE INSTALLATION

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK.

By purchasing this product and opening the packaging, purchasers expressly acknowledge, understand and agree that they take, select and purchase these SECTOR 111 products from SECTOR 111, its affiliates, distributors, and agents (collectively, SECTOR 111) "as is" and "with all faults".

The entire risk as to the quality and performance of these SECTOR 111 parts is with the purchasers. Working on your car can be a dangerous activity. If you are unsure of what you are doing, please leave mechanical or Safety critical work to a skilled mechanic.

We take no responsibility for the incorrect use and/or installation of SECTOR 111 products.

Rear Panel Eliminator Kit-Instructions

Items included:

- 2 side stems
- 1 upper license plate bracket (labeled 'T')
- 1 lower license plate bracket
- 4 10mm nuts
- 4 lock washers

Tools Required:

- 8mm socket
- 5mm Allen wrench
- 10mm socket
- a 3rd hand
- patience

1. Remove both 5mm Allen bolts securing diffuser
2. Remove 8mm bolts around diffuser. Remove diffuser.
3. Remove carpeting and foam insulation from rear trunk. There are 3 10mm bolts securing rear panel to clam that are located towards the rear of the trunk. Remove bolts.
4. If you want to remove heat shield from car, see step 4a. If you do not need to remove heat shielding, go to step 5.
 - a. To remove heat shielding, it is easiest if the muffler is removed. Once muffler is removed, the heat shielding can be taken off by removing 8mm bolts securing shielding to car.
5. Remove brass "clip nuts" on top, and grey "clip nuts" on bottom of rear panel. On the rear panel eliminator kit, place brass clips on segments labeled "T" for top, and grey clips on opposite ends. Make sure the flat portions of the clip (screw in portions) are on the outside of the mounts and arms.
6. The eliminator kit can only be mounted one way. The top tabs on the license plate mount and side arms must be facing outward of the rear of the car, and the bottom tabs must be facing towards the car. It is easiest to secure tops of stems and license plate bracket to base of trunk first. Having a second person to help line up bolts is helpful but not necessary. DO NOT TIGHTEN yet, keeping tops of kit fairly loose, as you want to

make sure that the bottom of the stems are lined up with the holes in the diffuser. For perfect alignment, the bottom of the stems must be pointing towards the car and angled slightly towards the wheels such that the lower portion of the side stems are further apart than the upper portion.

7. Reattach diffuser on sides, undertray, and allen bolt locations. Save eliminator kit for last.

8. Align side arms to holes in diffuser and lightly secure. Once in place, tighten top 10mm bolts followed by bottom 8mm bolts. The diffuser is now secure.

9. To add license plate bracket, place lower bracket on diffuser such that tab is facing. Again, do not tighten until everything is in place. Attach license plate using stock 10mm bolts and secure with supplied nuts and lock washers. Tighten all bolts securing plate and top and bottom license plate brackets.

If you have any questions, please contact info@sector111.com or 951-296-6762