

sector 111

The re-ENFORCER Installation Instructions

Rev. A

Page 1 of 4

Assembly Step

Tools/ Parts

Detailed Instructions

Picture/ Illustration

READ FITTING INSTRUCTIONS IN FULL BEFORE INSTALLATION

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK.

By purchasing this product and opening the packaging, purchasers expressly acknowledge, understand and agree that they take, select and purchase these SECTOR 111 products from SECTOR 111, its affiliates, distributors, and agents (collectively, SECTOR 111) **as is** and **with all faults**.


The entire risk as to the quality and performance of these SECTOR 111 parts is with the purchasers. Working on your car can be a dangerous activity. If you are unsure of what you are doing, please leave mechanical or Safety critical work to a skilled mechanic.


We take no responsibility for the incorrect use and/or installation of SECTOR 111 products.


1. Remove Center Console

- Allen Key
- Phillips Screw Driver

- a. Remove shift knob and parking brake handle.
- b. Pull parking brake lever up to its full and locked up right position.
- c. Remove 2 screws that hold on the small cubby on the back of the center console.
- d. Remove 2 screws on the front

Assembly Step	Tools/ Parts	Detailed Instructions	Picture/ Illustration
		<p>of the center console.</p> <p>e. Unplug the hazard light switch, power door lock switch, 12-volt power supply, and traction control switch if present.</p> <p>f. Put shifter in 3rd gear position and carefully lift out the center console. It may be necessary to pull the emergency brake farther up or adjust to allow the lever to travel farther up.</p>	
<p>2. Remove Left Shifter Housing Bolt</p>	<ul style="list-style-type: none"> • Ratchet • Socket • Extension 	<p>a. Remove the bolt on the left of the shifter housing, but leave the center bolt in place.</p>	

Assembly Step	Tools/ Parts	Detailed Instructions	Picture/ Illustration
<p>3. Drill 2 Holes for re-ENFORCER Bolts</p>	<ul style="list-style-type: none"> • Drill • Supplied Drill Bit 	<ol style="list-style-type: none"> a. Use the supplied long drill bit and drill the far left hole directly through the threaded area and through the bottom of the car. b. Repeat this for the far right hole. c. Be sure to keep the drill straight up and down as you drill. 	
<p>4. Fit Aluminum Under-plate to Bottom of Car</p>	<ul style="list-style-type: none"> • Sealer 	<ol style="list-style-type: none"> a. Take the supplied aluminum plate and test fit. b. Apply a small amount of sealer to the side of the plate that comes in contact with the car and put the plate back in place. 	

Assembly Step	Tools/ Parts	Detailed Instructions	Picture/ Illustration
<p>5. Bolt Under-plate in Place</p>	<ul style="list-style-type: none"> • Sealer • 8mm Allen Wrench • Ratchet • Socket 	<ol style="list-style-type: none"> a. Apply a small amount of sealer to one side of each large washers. b. Place the large washers on the aluminum plate so that the holes from the washers line up with the holes you drilled in step 3. c. Insert 8mm button head cap screws from the bottom up, through the large washers, then through the aluminum under-plate, through the chassis and into the drivers compartment. d. Place the flat washers and nylock nuts onto the button head cap screws and tighten. e. Be sure not to over tighten bolts as the floor structure will collapse. 	
<p>6. Re-install Center Console</p>		<ol style="list-style-type: none"> a. Reverse the step 1 to re-install your center console. 	