



READ FITTING INSTRUCTIONS IN FULL BEFORE INSTALLATION

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK.

By purchasing this product and opening the packaging, purchasers expressly acknowledge, understand and agree that they take, select and purchase these SECTOR 111 products from SECTOR 111, its affiliates, distributors, and agents (collectively, SECTOR 111) "as is" and "with all faults".

The entire risk as to the quality and performance of these SECTOR 111 parts is with the purchasers. Working on your car can be a dangerous activity. If you are unsure of what you are doing, please leave mechanical or Safety critical work to a skilled mechanic.

We take no responsibility for the incorrect use and/or installation of SECTOR 111 products.

CRDmount installation instructions

Kit Includes:

- One CRDmount bracket
- One ring clamp
- Two 3/16" Allen bolts
- Two 2.5mm Allen screws
- Foam spacer (to be used w/ smaller than 1.25" diameter harness bars)
- 2 Velcro strips (to mount Radar Detector to platform)

1. Unscrew 3/16" Allen bolts from ring clamp and slide over harness bar. Reattach.
Note: If using mount on 4Tress bar, the rubber spacer is unnecessary. On bars smaller than 1/25" diameter, remove cardboard liner and secure foam to inside portions of ring clamp.
2. Adjust bracket level by loosening 2.5mm Allen screws.
3. If using a Radar Detector, attach Velcro strips to platform and bottom of Radar Detector.