

sector 111

Braille Intensity 480R

Rev. A

Page 1 of 3

READ FITTING INSTRUCTIONS IN FULL BEFORE INSTALLATION

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK.

By purchasing this product and opening the packaging, purchasers expressly acknowledge, understand and agree that they take, select and purchase these SECTOR 111 products from SECTOR 111, its affiliates, distributors, and agents (collectively, SECTOR 111) **as is** and **with all faults**.

The entire risk as to the quality and performance of these SECTOR 111 parts is with the purchasers. Working on your car can be a dangerous activity. If you are unsure of what you are doing, please leave mechanical or Safety critical work to a skilled mechanic.




We take no responsibility for the incorrect use and/or installation of SECTOR 111 products.



1. Confirm the following items are in your kit

- Braille lithium battery
- 1 3/8x16x5/8" bolt
- 1 3/8x16x1/2" bolt

Tools needed for install:

- 9/16" socket
- Drill
- 23/64 drill bit
- Ratchet
- 10mm socket
- 8mm socket
- Vise grip

Instructions	Tools/ Parts	Picture/ Illustration
2. Remove cargo net hooks from trunk		
3. Pull back carpet to expose battery panel		
4. Remove panel bay unscrewing the three panel holders.		

Instructions	Tools/ Parts	Picture/ Illustration
<ol style="list-style-type: none"> 5. Unbolt battery hold down 6. Pull battery out slightly and unbolt leads from terminal post 7. Remove Battery 	<ul style="list-style-type: none"> ○ 8mm, 10mm socket ○ Ratchet 	
<ol style="list-style-type: none"> 8. Using vise grips hold each connector and enlarge connector using a drill. There are three connectors, 2 positive and 1 negative 9. Once all three leads are drilled attach to lithium battery using 5/8" length for positive and 1/2" length for negative 	<ul style="list-style-type: none"> ○ Drill ○ 23/64 Drill bit 	
<ol style="list-style-type: none"> 10. Reinstall new battery using battery hold down. 11. Press button on top of Battery to activate battery 12. Reinstall panel, carpet, and cargo hooks 13. Reset windows and radio stations 	<ul style="list-style-type: none"> ○ 8mm socket ○ Ratchet 	