

### READ FITTING INSTRUCTIONS IN FULL BEFORE INSTALLATION

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK.

By purchasing this product and opening the packaging, purchasers expressly acknowledge, understand and agree that they take, select and purchase these SECTOR 111 products from SECTOR 111, its affiliates, distributors, and agents (collectively, SECTOR 111) **as is** and **with all faults**.

The entire risk as to the quality and performance of these SECTOR 111 parts is with the purchasers. Working on your car can be a dangerous activity. If you are unsure of what you are doing, please leave mechanical or Safety critical work to a skilled mechanic.

We take no responsibility for the incorrect use and/or installation of SECTOR 111 products.



1. Confirm the following items are in your kit.


- 1 2-Eleven BBhook
- 3 M6 bolts
- 2 M6 nuts
- 5 M6 washers

Tools needed for this install:

- 8mm Socket
- 10mm Socket
- 10mm wrench
- 14mm Socket
- 15mm deep well Socket
- 5mm Allen or 13mm Socket (diffuser)
- Thread lock
- Ratchet
- Drill
- 11/32 Drill bit
- Phillips screwdriver



Instructions	Tools/ Parts	Picture/ Illustration
<ol style="list-style-type: none"> <li>2. Lift rear of car and place on stands</li> <li>3. Remove left rear wheel</li> <li>4. Remove rear diffuser</li> <li>5. Remove Exhaust</li> <li>6. Remove Cat pipe at spring bolts                             <ul style="list-style-type: none"> <li>o Prop up in manifold opening or unclip O2 sensor connectors</li> </ul> </li> </ol>	<ul style="list-style-type: none"> <li>o 8mm socket</li> <li>o 5mm Allen or 13mm socket</li> <li>o 15mm socket</li> <li>o 14mm socket</li> <li>o Ratchet</li> </ul>	
<ol style="list-style-type: none"> <li>7. Remove rear most Fender well fastener</li> <li>8. Remove Exhaust hanger bushings</li> <li>9. Measure 1/2" in from edge of sub frame and 1/2" in from inside. This will be the drill mark for the center bolt</li> </ol>	<ul style="list-style-type: none"> <li>o 8mm socket</li> <li>o Ratchet</li> <li>o Phillips screwdriver</li> </ul>	

Instructions	Tools/ Parts	Picture/ Illustration
<p>10. Drill sub frame at your mark</p>	<ul style="list-style-type: none"> <li>○ Drill</li> <li>○ 11/32 Drill bit</li> </ul>	
<p>11. Place BBhook into frame and install bolts through drilled hole and fender well from the inside out</p> <p>12. Place 2 washers between BBhook and sub frame for threaded hole and install last bolt and washer .Use thread lock.</p> <ul style="list-style-type: none"> <li>○ Spacing may vary use one or more washers as required.</li> </ul> <p>13. Use thread lock and install washer and nuts onto first two bolts</p> <p>14. Reinstall Cat pipe, Exhaust, Diffuser</p> <p>15. Reinstall wheel and torque to 77ft-lbs</p>	<ul style="list-style-type: none"> <li>○ 8mm Socket</li> <li>○ 10mm Socket</li> <li>○ 10mm wrench</li> <li>○ 14mm Socket</li> <li>○ 15mm deep well Socket</li> <li>○ 5mm Allen or 13mmSocket (diffuser)</li> <li>○ Thread lock</li> <li>○ Ratchet</li> </ul>	